

PA200 BlueRay Probe System

This guide contains information to help prepare your facility for the arrival of your PA200 BlueRay probe station.



Facility requirements for thermal systems are listed separately. See the Facility Planning Guide specific to your thermal system for details.

Probe Station Requirements

Νοτε

Air and Vacuum	Vacuum	Less than 200 mbar absolute		
		Flow rate insignificant		
		8 mm hose (US 5/16-inch)		
	Compressed air for	 Filtered, dry and oil-free Minimum 4 bar to 8 bar maximum (58 to 116 psi) 		
	vibration isolation table			
		Flow rate insignificant		
		8 mm hose (US 5/16-inch)		
	For detailed information or configuration.	n thermal system requirements, refer to the ATT thermal facility planning guide for your		
Power	Probe station	• 100–240 V AC nominal, 50-60 Hz, 900 VA		
	Protection class	• I (IEC 61140)		
	Transient overvoltage	Overvoltage category II (IEC 60364-4-443)		
	Main connector – North America	Grounded IEC appliance inlet C14, according to IEC 60320,UL 498, CSA C22.2 no. 42 (for cold conditions) pin-temperature 70°C, 10 A, protection class I. A region dependent power cord connects IEC C14 to common local power plug (1 phase, grounded).		
	Main connector – Europe	 Grounded IEC appliance inlet C14, according to IEC 60320,UL 498, CSA C22.2 no. 42 (for cold conditions) pin-temperature 70°C, 10 A, protection class I. A region dependent power cord connects IEC C14 to common local power plug (1 phase, grounded). 		
	Main connector fuse	 2 x T10A (slow blow), 250 V, high breaking capacity (HBC) corresponding to IEC 60127-2 		
	Separate ground connection (PE)	 Fixed wiring between probe station ground rail and facility PE terminal with ring cable lug/screw terminals Wire according to IEC60332/UL2556 AWG12/4 mm²; isolation color: gn/ye Length: ≤ 5 m (17 ft) 		
Environmental	Humidity	• Tool area: 25% to 60%		
Conditions		Support equipment area: 25% to 60%		
	Temperature	• Operating range: 19°C to 24°C		
		• Target temperature: 22 C		
		NOTE Keep electronics rack side ventilators and air expellers clear for air circulation.		
	Altitude	• <2000 m (6500 feet)		
	Pollution level	• 1 (IEC 60664)		
	Clean room class	Class 6 corresponding to DIN EN ISO 14644-1		
	Tolerance	• 1K		
	Vibrations	The facility should be free of vibrations caused by other equipment.		
Reliability	MTBF 3000 h; MTTR 24 h	MTBF 3000 h; MTTR 24 h; availability 99%		

PA200 BlueRay

Dimensions (WxDxH)	Station	• 700 x 848 x 1099 min./1822 max. mm (27.6 x 33.4 x 43.3 min./71.7 max. inches)			
	Electronics rack	• 450 x 400 x 230 mm (17.7 x 15.7 x 9.1 inches), with connectors installed			
	Joystick controller	• 280 x 250 x 140 mm (11.0 x 9.8 x 5.5 inches), with connector installed			
	Control PC	Optionally integrated in VIT			
	Additional clearance	Front	800 mm (31.5 inches) for operator/installation		
		Back Left Right	 200 mm (7.9 inches) for cables 600 mm (23.6 inches) during installation or service 		
		Тор	• 400 mm (16 inches)		
	Optional instrument shelf	 Left side configuration: additional 95 mm (3.7 inches) required at left side, plus 640 mm (25.2 inches) clearance for pivot arm Rear side configuration: additional 123 mm (4.8 inches) required at rear, plus 230 mm (9.1 inches) front side clearance for pivot arm 			
Weight	Station (with vibration isolation table)	• 360 kg (794 pounds)			
Shipping	Probe station crate	• 1310 x 1310 x 1780 mm (51.6 x 51.6 x 70.1 inches)			
Dimensions (WxDxH) (approx. values)	Optional accessory crate	• 800 x 1200 x 750/970 mm (31 x 47 x 30 / 38 inches)			
Shipping Weight (approx. values)	Probe station crate	• 550 kg (1213 pounds)			
	Optional accessory crate	• 200 kg (441 pounds)			

PA200 BlueRay

Dimensions (mm)

Station



Top view



Station with Instrument Shelf



© Copyright 2018 -2021 FormFactor, Inc. All rights reserved. No part of this document may be reproduced, transmitted or displayed in any form or by any means except as duly authorized by FormFactor, Inc. FormFactor and the FormFactor logo are trademarks of FormFactor, Inc. All other trademarks are the property of their respective owners.

Important Notice

While the information contained herein is believed to be accurate as of the date hereof, no express or implied representations or warranties are made with respect to its accuracy or completeness. FormFactor, Inc., and its subsidiaries disclaim liability for any inaccuracies or omissions. All information is subject to change without notice.

Users are required to read and follow carefully all safety, compliance and use instructions. Users assume all loss and liability arising from the use of products in any manner not expressly authorized. The conditions and methods of use of products and information referred to herein are the entire responsibility of the user and, to the maximum extent permitted by applicable law, FormFactor, Inc., and its subsidiaries shall not be liable for any damages, losses, costs or expenses arising out of, or related to, the use thereof.

No license, express or implied, by estoppel or otherwise, under any intellectual property right is granted in connection herewith. Users shall take all actions required to avoid intellectual property infringement.

Corporate Headquarters

7005 Southfront Road Livermore, CA 94551 Phone: 925-290-4000 www.formfactor.com

